



## RATCHET STRAPS FOR HEAVIER LOADS


Our ratchet straps are equipped with powerful ratchets and in the assortment we have smaller ratchets from 800 kg to the larger ones that have a lashing capacity of 6000 kg. They are available both as endless version and with hooks at the ends.



### FUNCTION FASTY RATCHET STRAPS



1 Place the ratchet strap around the load. Protect the strap against sharp corners with edge protection.



2 Feed in the loose strap end in the axle's slot. Pull through the strap until it is tight, without being tensed.



3 Winch the handle back and forth until the desired lashing strength is achieved.



4 The strap should then be rolled at least 1.5-2 turns around the axle.



5 Push the handle down into rest position when the load is lashed to the desired tension.



6 To release the strap ratchet, pull the latch with your fingers.



7 Push down the handle completely backwards in order to release the axle's rotation lock.



8 In this position the strap can easily be pulled out and the axle is released and rotates.



Art. 180 FASTY RATCHET STRAP

1 pce endless, W=25 mm, L=500 cm, 800 kg. Black



Art. 182 FASTY RATCHET STRAP

1 pce with hooks, W=25 mm, 2-parts (L=30 + 470 cm), 800 kg. Black



Art. 186 FASTY RATCHET STRAP

1 pce endless, W=25 mm, L=500 cm, 1000 kg. Blue



Art. 187 FASTY RATCHET STRAP

1 pce with hooks, W=25 mm, 2-parts (L=30 cm + 470 cm), 1000 kg. Blue



Art. 188 FASTY RATCHET STRAP

1 pce with hooks, W=35 mm, 2-parts (L=50 cm + 450 cm), 2500 kg. Orange



Art. 189 FASTY RATCHET STRAP

1 pce with hooks, W= 50 mm, 2-parts (L=50 cm + 950 cm), 4000 kg. Orange



Art. 192 FASTY RATCHET STRAP

1 pce with hooks, W= 50 mm, 2-parts (L=50 cm + 950 cm), 6000 kg. Orange

Art no. 0180-0187 are delivered in plastic bag with header card and art no. 188, 189 and 192 are delivered in shrink plastic with sticker.

Scan the QR code  
and check out how to use  
our ratchet straps.

